

## Georgian Bar Tape Application Instruction Guide

We have a few recommendations to ensure you get the best results using our FoamLINK, ProLINK, CustomLINK and FlexLINK range on the Georgian Bar application.

1. Our FoamLINK, ProLINK, CustomLINK and FlexLINK products have a PSA “pressure sensitive adhesives” system, therefore when applying our product please make sure sufficient pressure is applied when being adhered to its application.
2. Please ensure that the surfaces the tape will be adhered to are clean from all dirt and dust by using an isopropanol cleaner, (please contact us for details on our recommended cleaner).
3. Please note that if the bars are cut too tight to the frame this will cause stress on the adhesive tape bond, we then suggest to leave an approximate 1mm gap between the bar and the frame at each end of the bar this will allow for expansion and contraction of the surfaces.
4. We also recommend that once the windows & bars have been glazed up, leave the finished product in despatch for at least 72 hours, before they are despatched, this will make a massive difference to the performance of the tape. All Acrylic adhesive systems take 72 hours to reach their optimum bond.

If you have any further queries regarding, please contact our Technical Sales Department on;  
**E:** [sales@ukindustrialtapes.co.uk](mailto:sales@ukindustrialtapes.co.uk) or **T:** 0191 269 7810

T: (0191) 269 7810 | F: (0191) 267 1028

E: [sales@ukindustrialtapes.co.uk](mailto:sales@ukindustrialtapes.co.uk) | [sales@postapes.co.uk](mailto:sales@postapes.co.uk) | [sales@stix2.co.uk](mailto:sales@stix2.co.uk)

Brumwell House, Westway Industrial Estate, Throckley, Newcastle Upon Tyne. NE15 9EW

[www.ukindustrialtapes.co.uk](http://www.ukindustrialtapes.co.uk) | [www.postapes.co.uk](http://www.postapes.co.uk) | [www.stix2.co.uk](http://www.stix2.co.uk)

